

Project Skill Level: Advanced DIY'er



For Best Results

To promote adhesion and durability of your topcoat, use a PREMIUM PLUS® primer. Not interested in applying a primer? Consider using PREMIUM PLUS ULTRA® products - innovatively developed as a paint and primer in one. If you are painting a cabinet that was previously painted with a glossy paint, thoroughly scuff, sand or degloss the surface for proper adhesion.

The Stiles and Openings

Step 1

Begin your painting project by pouring thoroughly mixed paint into a bucket and dipping a quality 2"-2½" wide nylon/polyester brush into the paint.

TIP: When using more than one gallon of paint, combine the colors for better color uniformity. This intermixing is called "boxing."



Step 2

With your brush, paint the inside edges of the cabinet door openings.

TIP: To avoid drips, tap off the excess paint against the inside wall of the bucket.



Step 3

Paint the middle stile from top to bottom following the wood grain. Then paint the remaining stiles in the following order: top, bottom, left, right.

TIP: Reload the brush when necessary to maintain a wet edge.



The Side Panels

Step 1

Using your brush, paint (cut in) around the perimeter of the cabinet where it meets the ceiling, walls, countertops, and floor.



Step 2

Pour paint into a paint tray. Work the roller into the tray until it is fully loaded with paint. For best results, use a ¼" roller cover.

TIP: A brush may be used in the areas where a roller is not suitable.





Step 3

With your roller, paint the side panel of the cabinet. Be sure to roll over the cut in area as well. Continue until all side panels are complete.

TIP: Lightly roll over the entire panel to create a smooth, uniform finish.

The Paneled Doors



Step 1

Using your brush, paint the edges around the perimeter of the door.



Step 2

With the door open, begin painting into the recess of the door panel. Start at a corner of the recess and continue around its perimeter.

TIP: Reload the brush when necessary and maintain a wet edge.



Step 3

Continue painting the remainder of the panel until the entire panel is complete. Wipe away the excess paint that has overlapped onto the door frame.

TIP: A roller may also be used on the larger open areas of the cabinet to avoid brush strokes.



Step 4

Paint the door frame in the following order: top, bottom, left, right.



Step 5

Again with your brush, paint the backside of the door. Repeat the process until the project is complete. Leave the doors open until the paint is completely dry (dry times will vary depending on temperature and humidity).

TIP: For optimum results in quality of color and finish, apply a second coat.

Color Used: Riviera Sand 320E-3



How to Paint a Cabinet

Recommended BEHR Products

 PREMIUM PLUS ULTRA® Interior Paint & Primer in One

 PREMIUM PLUS® Interior Primers

 PREMIUM PLUS® Interior Paints

Suggested Equipment

 Brush (2"–2½")

 Bucket

 Bucket Grid

 Vinyl Gloves

 Ladder

 Paint Can Opener

 Paint Tray

 Paint Tray Liner

 Protective Apparel

 Rags

 Roller Cover

 Roller Frame

 Sandpaper (150–220 Grit)

 Stir Stick